



Screen the best ionic liquids for keratin dissolution by using COSMO-RS

Liu, Xue; Nie, Yi; Zhang, Suojia; Skov, Anne Ladegaard

Publication date:
2018

Document Version
Peer reviewed version

[Link back to DTU Orbit](#)

Citation (APA):

Liu, X. (Author), Nie, Y. (Author), Zhang, S. (Author), & Skov, A. L. (Author). (2018). Screen the best ionic liquids for keratin dissolution by using COSMO-RS. Sound/Visual production (digital)

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.

- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.


Screen the best ionic liquid for keratin dissolution by using COSMO-RS

Xue Liu⁽¹⁾⁽²⁾, Yi Nie⁽²⁾, Suojia Zhang^{(2)*}, Anne Ladegaard Skov^{(1)*}

(1) Danish Polymer Centre, Department of Chemical and Biochemical Engineering, Technical University of Denmark, Kgs. Lyngby, Denmark;

(2) CAS Key Laboratory of Green Process and Engineering, Institute of Process Engineering, Chinese Academy of Sciences, Beijing, China;




Application of PDMS in tissue engineering




- Most PDMS used in tissue engineering applications are **nonpolar, inert and highly hydrophobic**, which lead to the low biocompatibility and interaction responses between implantations and cells.

Structure of keratin and application of keratin in elastomer

Structure of keratin



Application of keratin in elastomer



Lee, Hanna, et al. Macromolecular Research 23.3 (2015): 300-308.

- Keratin molecules have many inter- and intra-molecular **strong bonds** and also have **no regular repeating units**, which lead to it **difficult to be dissolved by traditional solvent**
- Keratin has the **special amino acid sequence** for cell adhesion, which can **increase susceptibility** to bio-decomposition
- Keratin can improve the **mechanical properties** of composites

Keratin dissolution in ionic liquids

Ionic liquid (IL) is a salt in which the ions are poorly coordinated, which results in these solvents being liquid below 100°C, or even at room temperature

Properties of ILs

- ❖ High chemical stability and thermal stability
- ❖ Wider liquid state, Non-volatile
- ❖ Low vapor pressure
- ❖ Tunable structure and properties
- ❖ Wide electrochemical windows
- ❖ high electrical conductivity


Advantages of ILs in dissolving keratin

- ❖ Higher solubility
- ❖ It can be recycled with high recovery rate
- ❖ Less damage to keratin structure
- ❖ Tunable structure and properties


- It is nevertheless a challenge to identify the best ILs for keratin dissolution;
- Experimental measurement of all these systems is not practically feasible;
- A rapid and a priori screening method to predict the keratin solubility capacity for ILs is needed

Study of keratin dissolution in ionic liquids

Author	ILs	Temperature °C	Time	Solubility
Yimei Ji	[Bmim]Cl/Na ₂ SO ₃ /H ₂ O	90	1h	6.6
	[Bmim]Cl	100	10h	4
	[Bmim]Cl	130	10h	11
	[Amim]Cl	130	10h	8
Haibo Xie	[Bmim]Br	130	10h	2
	[Bmim]BF ₄	130	24h	ND
	[Bmim]PF ₆	130	24h	ND
Yun-Xian Wang	[HOEmim]NTf ₂ /NaHSO ₃	80	4h	2.5
	[Bmim]Cl	130	10h	50
	[Amim]Cl	130	10h	50
	[Choline][thioglycolate]	130	10h	45
Azlia Idris	Bis-(2-ethoxyethyl) ammonium[thioglycolate]	130	10h	ND
	[Bmim]Cl	130	5h	8
	[BPy]Cl	130	24h	ND
	[P ₄₄₄]Cl	130	24h	ND
	[N ₄₄₄]Cl	130	24	ND
Shuangshuang Zheng	[N ₁₁₁₁]DMP	130	3h	8
	[Emim]DMP	130	1.5h	8
	[Bmim]OAc	130	10min	8
	[Bmim]SCN	130	15h	8
	[Bmim]FeCl ₄	130	24	ND
	[Bmim]DMP	130	1.5h	8



EuroEAP 2018
International conference on Electromechanically Active
Polymer (EAP) transducers & artificial muscles
Lyon, France, 5-6 June 2018



Screen the best ionic liquid for keratin dissolution by using COSMO-RS

Xue Liu (1)(2), Yi Nie(2), Suojang Zhang (2)*, Anne Ladegaard Skov(1)*

(1) Danish Polymer Centre, Department of Chemical and Biochemical Engineering, Technical University of Denmark, Kgs. Lyngby, Denmark;
(2) CAS Key Laboratory of Green Process and Engineering, Institute of Process Engineering, Chinese Academy of Sciences, Beijing, China;

Poster ID:
2.2.3


Contact e-mail:
all@it.dtu.dk

Abstract

Dielectric elastomers (DEs), which are often referred to as "artificial muscles", possess many excellent properties, such as large strains, high energy densities, and fast responses[1]. Polydimethylsiloxane (PDMS) elastomers are one of the most used materials for DEs[2]. Unfortunately, most PDMS used in tissue engineering applications are nonpolar, inert and highly hydrophobic, which lead to the low biocompatibility and interaction response between implantations and cells. Keratin, which is **polar, hydrophilic, biodegradable and thermally stable**, is expected to enhance interaction responses between implantations and cells[3]. The bio-functions of silicone /keratin composites for tissue engineering could be achieved due to the special amino acid sequence in keratin. Moreover, keratin can **improve the mechanical properties** of composites, which probably results from the formation of a common spatial network between keratin and silicone elastomer[4]. But, wool keratin is difficult to dissolve in conventional solvents, due to the tight packing of the secondary structures in the polypeptide[5]. So efficient dissolution of keratin is the basis for the elastomer-keratin composites. As a new class of designer solvents, ionic liquids (ILs) can dissolve a large number of biopolymers, due to their unique properties like high thermal stability, tunable properties, and good dissolving ability[5,6,7]. But it is nevertheless a challenge to identify the best ILs for keratin dissolution. Experimental measurement of all these systems is not practically feasible, hence a rapid and a priori screening method to predict the keratin solubility capacity for ILs is needed. In this work, we designed three models containing disulfide bonds for describing wool keratin, and 462 ILs formed from 21 cations and 22anions were selected for evaluation of their ability to dissolve wool keratin by COSMO-RS. It lays a foundation for the research of keratin elastomer composites later.


1.Application of elastomer in elastomer materials

Structure of keratin



- Keratin has a complex structure, and there is a large number of inter- and intra-molecular strong hydrogen bonds and disulfide bonds
- Keratin molecules have no regular repeating units

Keratin elastomer composites




Lin, Xue, et al. *Nature Materials*. Research 23.3 (2024): 300-308.

Elastomer-keratin composites show an increased solubility to hot-decomposition


Keratin can improve the mechanical properties of composites

2.Structures of ILs and keratin models in this study


Structure of cations



Structure of anions




Structure of keratin models



Model 1: Cysteine Model 2: Glutathione (GSSG) Model 3: Glutathione-Cysteine (GSSG-Cys)

3.Predict result


Prediction of σ -potentials




Model 1 (Eys): Black
Model 2 (GSSG): Red
Model 3 (GSSG-Cys): Green

- Cys gives more affinity for H-bond acceptor surface
- GSSG gives more affinity for H-bond donor surface


σ -profiles of keratin models and cations




σ -profiles of keratin models and anions




Logarithmic activity coefficient(ln γ) of model 1 in 462 ILs




ln γ of model 2 in 462 ILs




ln γ of model 3 in 462 ILs




Excess enthalpy of keratin model 1



Excess enthalpy of keratin model 2



Excess enthalpy of keratin model 3



- Excess enthalpy between the three models and ILs have a high influence on the solubility of keratin
- Anions play a crucial role in the keratin dissolution process

Molar fraction of keratin model is 0.5, molar fraction of ionic liquid is 0.5 (cation molar fraction is 0.25, anion molar fraction is 0.25)

In the process of keratin dissolution, the solubility of keratin in ILs is affected by cation and anions, but the anion plays a leading role.

Ionic liquid with Ac, Dec, HCOO, CF₃, DMP, DMP, DMP, BEN or Br⁻ has excellent solubility of keratin.

4. Conclusions and Advances

- Three models containing disulfide bonds were designed for describing wool keratin;
- 462 ILs formed from 21 cations and 22anions were selected for evaluation of their ability to dissolve wool keratin by COSMO-RS;
- H-bond interactions between the three models and ILs have a high influence on the solubility of keratin;
- In the process of keratin dissolution, the solubility of keratin in ILs is affected by cation and anion, but the anion plays a leading role;
- Ionic liquid with Ac, Dec, HCOO, CF₃, DMP, DMP, BEN or Br⁻ has excellent solubility of keratin.

Advances of keratin application

The regenerated keratin will be used for designing structural and functional materials in the further work.

Acknowledgments and References

Acknowledgments

The authors gratefully acknowledge the National Natural Science Foundation of China (NSFC), Chinese Academy of Sciences (CAS)

References

- Pelrine, R., et al. *Science* 2000, 287, (5454), 836-839.
- Liu, C., et al. *Adv. Eng. Mat.* 2005, 7, (5), 361-367.
- Van Dyke, M., et al. U.S. Patent 2004, Application No. 10/606,279.
- Wambua, P., et al. *Compos. Sci. Technol.* 2003, 63, (9), 1259-1264.
- Liu, X., et al. *RSC Adv.* 2017, 7, (4), 1981-1988.
- Zhang, Z., et al. *ACS Sustain. Chem. Eng.* 2017, 5, (3), 2614-2622.
- Zheng, S., et al. *ACS Sustain. Chem. Eng.* 2015, 3, (11), 2925-2932.

Thank You!