



Phase Equilibrium in Amino Acid Salt Systems for CO₂ Capture

Sengeløv, Louise With; Thomsen, Kaj

Publication date:
2011

Document Version
Early version, also known as pre-print

[Link back to DTU Orbit](#)

Citation (APA):
Sengeløv, L. W. (Invited author), & Thomsen, K. (Invited author). (2011). Phase Equilibrium in Amino Acid Salt Systems for CO₂ Capture. Sound/Visual production (digital)

General rights

Copyright and moral rights for the publications made accessible in the public portal are retained by the authors and/or other copyright owners and it is a condition of accessing publications that users recognise and abide by the legal requirements associated with these rights.


- Users may download and print one copy of any publication from the public portal for the purpose of private study or research.
- You may not further distribute the material or use it for any profit-making activity or commercial gain
- You may freely distribute the URL identifying the publication in the public portal

If you believe that this document breaches copyright please contact us providing details, and we will remove access to the work immediately and investigate your claim.

Phase Equilibrium in Amino Acid Salt Systems for CO₂ Capture

Louise With Sengeløv and Kaj Thomsen (kth@kt.dtu.dk)

Porsgrunn, February 3rd 2011



Outline

Introduction

- General introduction
- Experimental data for amino acid salt systems
- Methionine as a case study

Carbonate-Methionine system

- Equilibrium constants
- Vapor-Liquid equilibrium data
- Freezing point depression data
- Thermodynamic modelling

Comparison of absorbents

- Absorber conditions
- Desorber conditions
- Heat of desorption
- Conclusion

Introduction


Advantages in using amino acid salts instead of alkanolamines:

- Might be less prone to degradation in oxygen rich environments
- Less volatile than alkanolamines due to their ionic nature
- Same affinity towards CO_2 as alkanolamines
- Form carbamates

Amino acids participate in the transportation of CO_2 in the blood by the formation of carbamate

Problems and drawbacks:


- More expensive
- Limited solubility of amino acids in water
- Limited amount of experimental data available in literature



Experimental data for amino acid salt solutions


- **CO₂ Equilibrium data**
 - Potassium taurate – Kumar *et al.* (2003) **38 data points**, T=25 and 40°C
 - Potassium glycinate (Portugal *et al.* 2009) **103 data points**, T= 20-50°C
 - Potassium methionate (Kumelan *et al.* 2010) **65 data points**, T= 80-120°C
 - Potassium sarcosinate (Aronu *et al.* 2010) graph with 55 points, T=40-120°C
 - Potassium proline (unpublished, DTU, UTwente)
- **Absorption kinetics**
 - Kumar *et al.* (2003) (potassium salt of taurine and glycine)
 - Van Holst *et al.* 2009 (potassium salts of 7 different amino acids)
 - Prakash *et al.* 2010 (potassium salts of taurine and glycine)
- **Equilibrium constants**
 - Sharma *et al.* 2003
 - Hamborg *et al.* 2007
- **Heat capacity and other thermal properties - none**
- **Freezing point depression data**
 - Sengeløv (2010) (loaded and unloaded potassium salt of methionine) **20 data points** -14 to 0°C

Methionine, C₅H₁₁NO₂S




- Molar mass 149.21 g/mol
- Decomposition temperature 281°C
- Solubility in water at 25°C: 0.38 molal
- pKa 2.28 and 9.21
- Found in cereal grains and in nuts

Iso-electric point of methionine



Solubility of methionine in water **O** and in NaCl solution **X**

Hill and Robson, Biochemical
Journal, 28(1934)1008-1013




Potassium salt of methionine – Equilibrium constants

- Sharma VK; Zinger A; Millero FJ; De Stefano C; *Dissociation constants of protonated methionine species in NaCl media*, Biophysical Chemistry, 105(2003)79-87
 - Determined in temperature range 5 – 45°C
- Hamborg ES; Niederer JPM; Versteeg GF; *Dissociation constants and thermodynamic properties of amino acids used in CO₂ absorption from (293 to 353) K*, J. Chem. Eng. Data, 52(2007)2491-2502
 - Determined in temperature range 20 – 80°C
- Equilibrium constant for the carbamate formation of methionine not available
- Equilibrium constant for the protonated form of methionine not relevant at pH above 6


Potassium salt of methionine – experimental data

- Kumelan J, Pérez-Salado Kamps A, Maurer G, *Solubility of CO₂ in Aqueous Solutions of Methionine and in Aqueous Solutions of (K₂CO₃ + Methionine)*, Ind. & Eng. Chem. Res. 49(2010)3910-3918
 - VLE-data for the system CO₂-H₂O-K₂CO₃-Methionine at 80-120°C
 - It corresponds to loaded solutions of potassium salt of methionine
 - Some precipitation in experiments at 80°C with 2.5 molal K₂CO₃ and 0.83 molal methionine
- Sengeløv L., Bachelor Thesis, Technical University of Denmark, 2010
 - Freezing point depression data for potassium salt of methionine and for loaded solutions of this salt

**Results for
the CO₂-H₂O-
K₂CO₃-
Methionine
system
(Eq. constant
from Sharma et
al.)**




Results for the CO₂-H₂O-K₂CO₃-Methionine system (Equilibrium constant from Sharma et al.)




$m(\text{K}_2\text{CO}_3) \approx 1.27 \text{ mol}/(\text{kg H}_2\text{O})$ & $m(\text{Met}) \approx 0.42 \text{ mol}/(\text{kg H}_2\text{O})$

Measurements of freezing point depressions for mixtures of 1:1 (mole ratio) aqueous Met-KOH and 1:3 (mole ratio) aqueous Met-K₂CO₃





Freezing point depressions: Results and model correlation (Equilibrium constant from Sharma *et al.*)





The potassium salt of methionine as an absorbent in post-combustion contra MEA, MDEA and K_2CO_3

Absorber
conditions

Equilibrium
constant from
Sharma et al.







Equilibrium
constant from
Hamborg et al.



The potassium salt of methionine as an absorbent in post-combustion contra MEA, MDEA and K_2CO_3

Desorber
conditions





Equilibrium
constant from
Sharma *et al.*



The potassium salt of methionine as an absorbent in post-combustion contra MEA, MDEA and K_2CO_3

Desorber
conditions

Equilibrium
constant from
Hamborg *et al.*



Conclusion I

- The extreme difference between the properties of the potassium salt of methionine at absorber conditions and at desorber conditions indicates:
 - A strong temperature dependence of the equilibrium constant of methionine
 - Acidic properties of methionine strongest at desorber temperature
- Portugal et al. found that the carbon dioxide solubility in potassium glycinate did not change much in the temperature range investigated (20-50°C)

Conclusion II

- Due to the limited amount of experimental data available, it is possible to model CO₂ solubility in amino acid salt solutions without taking carbamate formation into account
- The potassium salt of methionine seems to have very interesting properties for post-combustion usage. However VLE-data at absorber column conditions are needed to validate the results
- The limited solubility and risk of precipitation provide challenges in the use of the potassium salt of methionine and must be investigated further
 - The 2 molal solutions for which calculations were shown here might be precipitating!
- More research is required to clarify the role of methionine in the absorption process: Especially regarding carbamate formation and kinetics
- Much more research is required on amino acid salt solutions. They have very interesting properties and could be real alternatives to alkanolamines.